

cod.1098M0419

ELLIPSIS V 2 ELLIPSIS H 2

Istruzioni di montaggio ed uso
Operation instructions
Instructions de montage et usage
Montage- und Bedienungsanleitung
Instrucciones de montaje y uso
Instrucțiuni pentru montare și utilizare

IRSAP


creating your comfort

IRSAP SPA
45031 Arquà Polesine (RO) Italy
Tel. +39 0425 466611 - Fax +39 0425 466662
Website: <http://www.irsap.com>
E-mail: info@irsap.it

IR GROUP SARL
19, Chemin de la Plaine 69390 Vourles (France)
Tel. +33 04 28 00 01 67 - Fax +33 04 72 31 86 40
Web: <http://www.irsap.com>
E-mail: irsaphoss@irgroup.fr

IRSAP IBERICA S.L.
Oficina y Almacén: P.I.CAMI RAL
Leonardo da Vinci, 4 08850 Gavà (Barcelona)
Tel. 93 633 47 00 - Fax 93 633 47 04
E-mail: www.informacion@irsap.com
www.irsap.com

IRROM Industrie S.R.L.
Str. Pricipală 1/A, Sat Fundătura, Iclod 407336,
jud. Cluj, România
Tel: +40 (0)264 263400 - Fax: +40 (0)264 263404
Web: www.irsap.ro



| H | n° | | | | |
|------|----|------|-------|-------|-------|
| | 2 | 3÷21 | 22÷23 | 24÷28 | 29÷30 |
| 520 | 2 | 4 | 4 | 4 | 4 |
| 650 | 2 | 4 | 4 | 4 | 4 |
| 700 | 2 | 4 | 4 | 4 | 4 |
| 920 | 2 | 4 | 4 | 4 | 4 |
| 1020 | 2 | 4 | 4 | 4 | 4 |
| 1220 | 2 | 4 | 4 | 4 | 4 |
| 1520 | 2 | 4 | 4 | 4 | 6 |
| 1820 | 2 | 4 | 4 | 6 | 6 |
| 2020 | 2 | 4 | 6 | 6 | 6 |

